



HT580-26LA59

Pin	Function
1	R/N
2	L/R
3	NC
4	P5C
5	P5T
6	V5Y
7	C5K
8	5V
9	B
10	B
11	-15V
12	+17V
13	CSY
14	FRP
15	HSY